



**Starting Line
Products, Inc.**

*"Setting the World's
Performance Standards!"*

743 E. Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

Upper Dash Intake Vent for Polaris IQ

Part #14-135

Parts List:

- 1 - Intake Vent
- 3 - 3/16" Plastic Rivets

1. Cut out the provided template and align on the left hand side of the gauge and mark around the inside of the template.
2. Use a multi-purpose cutting tool, cut out the inside of the marked line and debur the hole.
3. Using the intake vent as a guide drill the 3 holes using a 3/16" drill bit and rivet into place.

NOTE: Air plenum on the under side of the hood needs to be removed to clean out all plastic shavings. Failure to do so can result in severe engine damage.

TEMPLATE

